

Trouble Messages

E01-00	Power Failure
E02-00	Low Battery
E03-00	Communication Fail
E04-NN	Wireless Transmitter Fail
E05-NN	RF Transmitter Fail
E06-NN	RF Receiver Fail
E07-00	Download Fail
E08-00	Telephone Fail
E09-00	System Cold Start, Not Program After Address 1198
E10-NN	Keypad Failure
E11-NN	Keypad Tamper
E12-NN	Expansion Zone Failure
E13-NN	EZM Cover Removed
E14-NN	Relay Board Failure
E15-NN	Wireless Transmitter Tamper
E16-NN	Receiver Fail
E17-NN	Receiver Cover Removed
E18-NN	Keyfob Low Battery
E19-00	Internal User Memory Error
E20-00	Internal Dealer Memory Error
E21-NN	Gem-Print Module Error
E22-NN	No Trip Detected on PIR Zone
E23-00	Failure of 4 Wire Bus
E27-00	Printer Failure
E39-00	Receiver Capacity Error
E40-00	RF Self - test Failure
E41-NN	Fire Zone Failure
E51-NN	Alarm Output failure
E66-00	Smoke Detector Dirty
E99-00	Keypad Panic Short Too Long